

## Changing Channels -- NXT Clicker

1. Press the channel button.



2. Type in the number of the correct channel. As you type in the number it will appear in the box on the screen.



3. Press the silver button in the center of the arrow keys.



4. A message will appear on your screen showing that the channel has been changed successfully.

